



Advanced Technologies for Clean Spaces

novanex™
time and messaging solutions



Digital PoE Clocks

When furnishing a cleanroom, it is not unusual to forget to include an accurate clock. Novanex Digital Clocks are specifically designed for cleanrooms that require accurate synchronized time, have high visibility and can withstand any cleaning regime. Novanex Digital Clocks are built on Power over Ethernet (PoE) technology where both the time and the power are provided by the network through a powered ethernet cable.

- Wall-mounted (surface or recessed) or hallway-mounted
- Does not require a master clock, electrical outlets or batteries
- Stainless Steel trims to with stand the harsh cleaning regime and chemicals
- Available with red or green LED numerals, 4 digits or 6 digits
- Time is set automatically by Simple Network Time Protocol (SNTP) and is accurate within 200 milliseconds
- Visible from 150+ feet
- Low power consumption 9.5 watts max
- Easy to install, virtually no maintenance
- 3 Year Warranty
- Designed and built in the USA

NOVANEX:

Novanex, Inc has been making electronics in Charlottesville, Virginia for over 30 years. Originally called Inova Solutions, in 2018 the company was rebranded to Novanex, Inc. They are the leading manufacturer of high quality PoE Clocks and Messaging Signs.



Advanced Technologies for Clean Spaces



844.899.4GMP
spscleantech.com